



# Miller Diving Equipment

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.millerdiving.com email: info@millerdiving.com

## Part #915-038 & 915-040 Earphone Mount Left & Right Strips

Part #	Description	Qty
915-038	Earphone Mount, Left	1
915-040	Earphone Mount, Right	1



In order to glue in the earphone mount Velcro® P/N 915-038, Left and 915-040, Right strips, first you will need to clean the area with acetone. If acetone is unavailable then at the very least clean the area with isopropyl alcohol. Apply 1<sup>st</sup> coat of wetsuit glue to the Velcro® strip and to the inside of the shell (ear pocket) and let dry. When dry apply 2<sup>nd</sup> coat of wetsuit glue and wait until the glue becomes tacky then place Velcro® strips in place in the shell (ear pocket) and let dry. *See figure above.*

### **⚠ CAUTION**

**Use only Miller Diving original replacement parts. The use of other manufacturer's parts will interfere with the performance characteristics of your life support equipment and may jeopardize your safety. Additionally, any substitutions will void any warranties offered by Miller Diving. When ordering spares, always insist on Miller Diving Genuine Parts.**